ALFA
N E T W O R K

AWUS036ACU

802.11ac WiFi AC1200 USB Adapter

Windows Install Guide

Contents

For Windows 10 none WPA3 driver install

Step 1:

Download driver from ALFA website (www.alfa.com.tw) and choose your ALFA USB antenna model

Step 2:

Unzip and click "Setup.exe" start to Install the driver and follow the setup steps

① Setup.exe

REALTEK USB Wireless LAN Driver and Utility ✕

REALTEK USB Wireless LAN Driver and Utility

The InstallShield Wizard will install REALTEK USB Wireless LAN Driver and Utility on your computer. To continue, click Next.

② < Back   Next >   Cancel

Step3:

Click desktop icon "REALTEK USB Wireless LAN Utility" or on the taskbar "Utility" icon

REALTEK USB Wireless LA…

Step4:

Click "Available Network" and select the Network SSID you want to connect and type-in security key if it required, then wait few seconds, when it connects the Status will show "Associated"

For Windows 10 WPA3 supported driver install

Note: The Windows 10 WPA3 driver doesn't have "REALTEK USB Wireless LAN Utility" **ONLY** can use Windows 10 Wi-Fi settings

Step1:

Download driver from ALFA website (www.alfa.com.tw) and choose your ALFA USB antenna model

Then choose " Windows 10 WPA3 driver"

Step2:

Unzip and click "Setup.exe" start to Install the driver and follow the setup steps

Step3:

Select the Network icon on the taskbar and choose the Wi-Fi network you want, then select Connect.

Type the network password, and then select Next